

INSTALLATION INSTRUCTION

NOZZLE INSTALLATION ON PIPE

FILTER NOZZLE P BOLT TM

Insert the bolt TM manually into the pipe hole, do not use hammer.

Check holes in the pipe
Make sure the hole diameter is 28-28.5mm - suitable for the TS expansion bolt dimension

1

Place the Nozzle

Introduce the nozzle's stem into the TM expansion bolt and manually screw the nozzle holding the bolt

Check pipe thickness!
Each pipe thickness requires the correct expansion bolt TM
TM1 - TM2 - TM3 - TM4

2

Screw clockwise the Nozzle
Torque set 5-10Nm
Max screw speed 400rpm

Check the assembly!
The Nozzle and the bolt should not move, the soft saddle must join perfectly to the pipe

3

ISTRUZIONI DI INSTALLAZIONE

INSTALLAZIONE UGELLO SU TUBO

UGELLO P TASSELLO TM

Inserisci il tassello TM
manualmente nel foro del tubo,
non usare il martello.

1
Controlla il foro del tubo!
Assicurati che il diametro del
foro sia 28-28.5mm - adatto per
il montaggio del tassello TM

Inserisci l'Ugello
Inserisci il codolo dell'ugello nel
tassello ad espansione TM e
manualmente avvita l'ugello
tenendo fermo il tassello

2
Verifica lo spessore tubo!
Ogni spessore di tubo richiede
il tassello TM corretto
TM1 - TM2 - TM3 - TM4

Avvita in senso orario l'Ugello
Set dinamometro 5-10Nm
Max velocità 400rpm

3
Controlla l'assemblaggio!
L'ugello ed il tassello non
devono muoversi, la sella
morbida deve aderire al tubo