

FILTER NOZZLE + SLEEVE MT



Insert the MT sleeve into the hole of the pipe and verify that the tabs are hooked. The sleeve will not have to go out.



Check holes in the pipe!
Hole for sleeve MT
range 31,5 - 32,0 mm



Introduce the Nozzle's stem into MT sleeve and screw it



Check pipe thickness!
Each thickness of the pipe
requires the right sleeve MT

SUGGESTED

SOAPY WATER TO MAKE THE
SCREWING EASIER



Torque setting 5.0 Nm
Screwing speed less than
200 rpm



Check the assembly!
The sleeve will not have to
move and have to join
perfectly with the pipe

SUGGESTED DEVICES

CHTW TORQUE SCREWDRIVER
CHTC TORQUE SCREWDRIVER

