

FILTER NOZZLE + EXPANDING BOLT TM

1

Insert the TM expansion bolt into the hole of the pipe and block it



Check holes in the plate!
Hole for expansion Bolt TS
range 28,0 - 28,5 mm

2

Introduce the Nozzle's stem into TM expansion bolt and screw it



Check pipe thickness!
Each thk requires the right
expansion Bolt TM
(TM1-TM2-TM3-TM4)

SUGGESTED DEVICES
CHDX LOCKING WRENCH

3

Torque setting 5.0 Nm
Screwing speed less than
400 rpm



Check the assembly!
The bolt will not have to
move and the saddle have to
join perfectly with the pipe

SUGGESTED DEVICES

CHTW TORQUE SCREWDRIVER
CHTC TORQUE SCREWDRIVER

