

## PLASTIC NOZZLES AND ACCESSORIES

- When possible protect the materials from frost, because the polypropylene is highly fragile at low temperature (near or lower than 0° C)
- When it is possible we suggest to avoid the nozzle's and accessories installation if the temperature is lower than 0° C.
- During periods of frost, before installation, we recommend to stock the nozzles and fittings into heated areas and to withdraw them to small quantities.
- At goods receipt, please inspect very well the condition of the packing to verify possible damages suffered during the transport.
- The pallets are completely wrapped with plastic film to protect the cartons from the rain and snow. so, when possible and when long time is foreseen, store the pallets in areas in which they are protected to the direct u.v. rays to avoid damages at the film.
- During the installation verify that the articles don't show damages or imperfections.
- The nozzle's installation can be handmade, with the help of the key wrench or with electrical or pneumatic tools or drills in which a tightening torque device must be foreseen.
  - Wrench setting: 0,5 mkp (5 Nm)
  - Screwing speed: less than 400 revs/min (200 revs/min where required)

Our technical service is available for further information



**Warning: Don't use hammers or iron objects to insert the nozzles and accessories into the holes. The holes in the plates or pipes must be of right diameter and checked before.**



**Warning: Don't use pipe wrenches or pliers to screw nozzles and accessories. Use the right wrenches for each product and if necessary request ILMAP the appropriate equipment.**



**Warning - Don't walk on the nozzles or plastic parts; for inspections and operation on the nozzle's system, it is necessary to put a wooden board on it to distribute the body's weight on a large number of nozzles.**